
HOW IT WORKS:

JamSync™ In Jack:

Connect this jack to the JamSync Out jack on another JamSync-compatible device to slave loop playback and stop functions from a master device.

JamSync™ Out Jack:

Connect this jack to the JamSync In jack on another JamSync-compatible device for master control over loop playback and stop functions.

Mic Output Jack:

Connect this balanced XLR output to the line or mic input of a mixer, or to the MIC IN jack of another JamMan Vocal XT device for multi-track vocal looping.

Power Jack:

Connect only the included power supply to this jack. The JamMan Vocal XT can only be powered by using an external adapter.

Status LEDs:

These LEDs are used to indicate: Recording, Overdub, and Playback status of loops. They are also used with the JamSync™ function to indicate an additional JamMan has been armed for recording and when synchronization between additional JamMan units has been established.

Loop Level Control:

This knob controls the output level of the loop. The 12 o'clock position represents unity gain.



Mic Input Jack:

Connect your mic to this XLR jack. If a condenser mic is being used, the +48V switch should be engaged.

+48V Switch:

Engage this switch to enable +48V phantom power for use with condenser microphones. Phantom power is on when the switch is in the 'in' position and off when the switch is in the 'out' position.

Mic Level Trim Control:

Adjust this trim control to set the input gain for your microphone. This trim control also doubles as a multi-color signal and clip indicator. It will light green when signal is present, orange when approaching the clip point and red when clipping occurs.

Footswitch

The Footswitch is used to activate all JamMan Vocal XT functions (i.e., record, play, overdub, undo/redo, stop, and clear loop).

Setup and Basic Looping with DigiTech JamMan Vocal XT:

To setup the JamMan Vocal XT for basic looping, connect your microphone to the JamMan Vocal XT's microphone input. Then connect the output of the JamMan Vocal XT to your mixer or powered speakers. Enable the +48V Phantom Power if you are using a condenser microphone.

Recording a Phrase

The JamMan Vocal XT records a single phrase and then plays it back as a continuous loop.

To record a phrase:

1. Press the Footswitch and begin singing to start recording. The REC LED will light solid red and recording will begin.
 2. When finished recording, press the Footswitch once to set the loop end point. The phrase will automatically begin playing back in a repeating loop and the PLAY LED will light solid green.
 3. Press the Footswitch 2 times quickly to stop loop playback.
-
-